

Energy-efficient heating with the RVD23... district heating controller

en Operating Instructions

You want to switch the heating on

1. Is the plant ready to operate? Check the mains isolator.
2. Check the time of day and the weekday (for readjustments, refer to section "You want to set the clock").
3. Press button **Auto**.

You want to heat in automatic mode

Automatic mode controls the room temperature according to the heating program entered.

1. Press button **Auto** (will light up).

You want to heat in continuous mode

In continuous mode, the room temperature is maintained at the level set with the setting knob.

1. Press button **XX** (will light up).
2. Adjust the required room temperature with setting knob.

You want to leave your home for a certain period of time

Set the plant to standby. It is then shut down, but will remain protected against frost.

1. Press button **U** (will light up).

Meaning of info given on the display

Bar under ... is lit	Meaning
	Nominal room temperature is maintained (adjustment made with the setting knob)
	Reduced room temperature is maintained
Display shows ...	Meaning
	Frost protection temperature is maintained
ECO	Presently no heating required
f or J	One of the limitation functions is active
BUS	Controller is connected to the data bus

You want to provide d.h.w.

First, adjust the required temperatures. You are given the choice of a normal and a reduced d.h.w. temperature.

Press ...	Display	Press to adjust the required temperature
	41		NORMAL d.h.w. temperature setpoint
	42		REDUCED d.h.w. temperature setpoint

For d.h.w. heating, you have the two choices:

Automatically:

Press button (button light steady on). The d.h.w. is heated up according to the time program.

Manually:

Press button for 3 seconds (as a confirmation, the button flashes for 3 seconds.). The d.h.w. is immediately heated up.

You want to readjust the temperature required for your rooms

1. Adjust the required nominal room temperature with the setting knob. The setting is active:
 - In automatic mode during the heating periods entered in the heating program
 - Always in continuous mode
2. Adjust the other temperatures and the heating curve using the buttons:

Press ...	Display	Press to adjust the required temperature
	01	Non-adjustable	Display of adjusted setting knob temp.
	02		Room temperature for reduced heating
	03		Room temp. for holidays/frost protection
	05		Heating curve slope

Your rooms are too cold or too warm

Especially in mild weather:

Readjust the room temperature with setting knob .

Especially in cold weather:

Readjust the heating curve slope on operating line .

- Room temperature too high: reduce slope by about 0.5
- Room temperature too low: raise slope by about 0.5

Especially in the night:

Readjust the temperature for reduced heating on operating line .

Each time you make a room temperature readjustment, wait two days. The controlled system requires time to adapt!

You want to set the clock

Press ...	Display	Press to set the time of day and the weekday
	13		Time of day
	14		Weekday
	15		Date (e.g. 02.12 = 2 nd December)
	16		Year

You want to change the heating periods

1. Select weekday whose heating periods you want to change:

Press ...	Display	Press to select the weekday or the entire week
	05		1 = Monday 2 = Tuesday, etc. 1-7 = entire week

2. For the selected weekday, enter the times required for the heating periods:

Press ...	Display	Press to adjust the start and the end
	07		Start of first heating period
	08		End of first heating period
	09		Start of second heating period
	10		End of second heating period
	11		Start of third heating period
	12		End of third heating period



You want to change the d.h.w. program

Your controller has a second time program.

If it is assigned to d.h.w. heating (contact your heating engineer), you can change it on operating lines **[1]** to **[7]**.

1. Select weekday whose program you want to change:

Press ...	Display	Press to select the weekday or the entire week
	[1]		1 = Monday 2 = Tuesday, etc. 1-7 = entire week

2. For the selected weekday, enter the times required for enabling d.h.w. heating:

Press ...	Display	Press to set the start and the end of the enabling periods
	[18]		Start of first period
	[19]		End of first period
	[20]		Start of second period
	[21]		End of second period
	[22]		Start of third period
	[23]		End of third period

During the enable phases, the d.h.w. is heated up to the normal temperature (set on operating line **[4]**), between the phases to the reduced temperature (set on operating line **[12]**).



You want to read the temperatures

Press ...	Display	... to read the temperature in °C
	[24]	Room temperature
	[25]	Outside temperature
	[26]	D.h.w. temperature
	[27]	Heating flow temperature



Which input has which number?

1. Press operating mode button lit.

2. Select the individual numbers by pressing

Number	Input	Number	Input
0	B9	7	B72
1	B1	8	B31
2	B3	9	B32
3	A6	10	B12
5	B7	11	DC 0...10 V
6	B71		

Contact your heating engineer.



You want to go on holiday

You can enter the dates of maximum 8 holiday periods per year:

Press ...	Display	Press to select the holiday number and the associated dates
	[31]		1 for the first holiday period of the current year
	[32]		Date of the first day of the first holiday period
	[33]		Date of the last day of the first holiday period
	[31]		2 for the second holiday period of the current year
Etc.	Etc.	Etc.	Etc.

During your holidays,

- the room temperature will be maintained at the holiday setpoint level entered on operating line **[13]**
- the d.h.w. will not be heated up



Your heating system does not operate as required

- Check the fault messages. Should faults occur, the display shows **Er** (error) and an error code. Contact your heating engineer and give him the error code displayed.

Press ...	Display	... to read the error code
	[50]	10 = error outside sensor circuit
		30 = error flow sensor heating circuit
		40 = error return sensor (primary side)
		42 = error return sensor 1
		43 = error return sensor 2
		50 = error storage tank sensor 1
		52 = error storage tank sensor 2
		54 = error flow sensor d.h.w. circuit
		61 = error room unit
		81 = short-circuit on bus
		121 = flow temperature heating circuit not reached
		123 = flow temperature d.h.w. circuit not reached

Other errors are possible, depending on the type of plant, configuration, etc.

- Does the operating mode button flash? If yes, the controller's operating mode is overridden by remote operation
- Are all fuses of the plant in order?
- Have controller settings been changed?
- Has the valve been disengaged from the actuator? If yes, engage it again



The controlled system has become defective

If the proper functioning of your heating control system is no longer ensured, press button (manual operation, button will light up). Now, you can manually regulate the supply of heat via the heating circuit valve by pressing buttons . Inform your heating engineer.



Energy savings tips

- During the day, do not allow room temperatures to exceed 21 °C
- Air rooms for short periods of time only, but with the windows fully open
- In unoccupied rooms, set the thermostatic radiator valves to their frost protection position
- Make certain there are no curtains, furniture, etc., in front of the radiators
- Close shutters and blinds whenever possible
- Check heat consumption at regular intervals