

CATALOG NUMBER

ECMM5J

electricCenter

ACCESSORIES

5th Jaw Kit

For use with Siemens and Murray products only

Same As:

■ D5JW ■ MJ369U



INSTALLATION INSTRUCTIONS



⚠ DANGER

Hazardous Voltage.
Will cause death, serious injury
or substantial property damage.

Turn off power supplying this
equipment before working inside.

Note: This instruction outlines the recommended installation procedure.

Install device in accordance with local and National Electrical Code requirements. Refer to wiring diagram label for specific details concerning application.



SAFETY INSTRUCTIONS

For use on Ring or Ringless type metering in 3, 6 or 9 o'clock position. (6 o'clock position shown)

1. Turn off and lock off the power supplying the device before working inside.
2. Place embossed cup of insulator into hole in meter socket base and push into place. May be inserted in 3, 6 or 9 o'clock position.
3. Install 5th jaw assembly with screw head at bottom of jaw nested in the embossed cup.
4. Align the opposite end with the neutral bus at the center of the socket.
5. Insert self threading #10-32 screw and tighten to 24-30 lb.-in.

