

SIEMENS

P2 Panelboard Kit DFK1 For Dead Front Coverage of 1" Pole Breaker Modules

Installation Instructions

The following instructions are for installation of a dead front center strip on the dead front of a Type P2 panelboard, to cover dual mounted 1" pole breakers and provisions. The parts provided in this kit will cover any standard 3" increment of 1" pole breaker unit space from a minimum of 3" to a maximum of 21".



⚠ DANGER

**Hazardous voltage.
Will cause death or
serious injury.**

**Keep out.
Qualified personnel only.
Disconnect and lock off all
power before working on this
equipment.**

1. Lock off power supplying this equipment before working on it.

3. Refer to Fig.1 - Measure the dead front opening to be covered by the new center strip. Select the correct center strip by matching the length of the side flange to the length of the dead front opening.

THIS KIT CONTAINS THE FOLLOWING ITEMS

ITEM NO.	DESCRIPTION	QTY.
1	3" Fill Center Strip	1
2	6" Fill Center Strip	1
3	9" Fill Center Strip	1
4	12" Fill Center Strip	1
5	15" Fill Center Strip	1
6	18" Fill Center Strip	1
7	21" Fill Center Strip	1
8	8-32 X 9/16" Self-threading Screw	4

4. Fasten the selected center strip to both adjacent dead front plates with four 8-32 screws (item 8). Tighten the screws to the torque values on the back of the dead front.

