



**de** Montageanleitung  
**en** Mounting instructions  
**fr** Instructions de montage  
**sv** Monteringsinstruktion  
**nl** Montage-handleiding  
**it** Istruzioni di montaggio  
**fi** Asennusohje  
**es** Instrucciones de montaje  
**da** Monteringsvejledning  
**pl** Instrukcja montażu  
**cz** Montážní návod  
**hu** Szerelési útmutató  
**el** Οδηγίες εγκατάστασης  
**ru** Инструкция по установке  
**zh** 安裝指導

**Schneckengetriebe**  
**Worm gear**  
**Engrenage à vis sans fin**  
**Snäckväxel**  
**Wormwielverstelling**  
**Ingranaggio a vite senza fine**  
**Vaihteisto**  
**Engranaje helicoidal**  
**Snekkedrev**  
**Przekładnia ślimakowa**  
**Šnekové kolo**  
**Kézi mozgató szerelvény**  
**Χειροκίνητος μοχλίσμος**  
**Червячная передача**  
**蜗轮式手动开关装置**


ASK46.4



1




4136Z09




4136Z10

2



4136Z13


3



4136Z14


4

4136Z15






5

4136Z16



6

4136Z17



4136M03

	DN	A	B	C	D	E	F	G	H	I	J	X	Y	kg [kg]
<b>ASK46.4</b>	250...400	252	67	200	129	60	29	137	150	60	62	22	100	3.38