


de Montageanleitung
en Mounting instructions
fr Instructions de montage
sv Monteringsinstruktion
nl Montage-handleiding
it Istruzioni di montaggio
fi Asennusohje
es Instrucciones de montaje
da Monteringsvejledning


I/O-Kompaktgerät
I/O Compact unit
Module E/S compact
Kompaktmodul
I/O-kompakt
Unità I/O compatta
I/O-kompaktlaite
Dispositivo Compacto E/S
Kompakt I/O-modul

PTK1...


A




B



C





D




Siehe Maßbilder am Schluss
 See dimensions on backpage
 Encombrements: voir en dernière page
 Se Måttuppgifter på slutet
 Zie maatschets op laatste blz.


Vedere le dimensioni alla fine
 Ks. lopussa olevat mittapiirrokset
 Dimensiones en la última página
 Mälskitser, se bagest

A







B




C






818LU6


D




818LU9




818LU10







818LU11



818LU13



818LU12

A**B****C****D**

Maße in mm
 Dimensions in mm
 Dimensions en mm
 Mått i mm
 Maten in mm
 Dimensioni in mm
 Mitat mm
 Dimensiones en mm
 Mål i mm