



- de** Montageanleitung
- en** Mounting instructions
- fr** Instructions de montage
- sv** Monteringsinstruktion
- nl** Montage-aanwijzing
- it** Istruzioni di montaggio
- fi** Asennusohje
- es** Instrucciones de montaje
- da** Monteringsvejledning

- Vandalenschutz** (Stellantriebe STA... / STP...)
- Vandal protection** (Actuators STA... / STP...)
- Protection anti vandalisme** (Servomoteurs STA... / STP...)
- Skydd mot åverkan** (Ställdon STA... / STP...)
- Molestvrij** (Aandrijvingen STA... / STP...)
- Protezione antivandalica** (Attuatori STA... / STP...)
- Ilkivaltasuojaus** (Toimilaitteet STA... / STP...)
- Protección contra vandalismo** (Actuadores STA... / STP...)
- Vandalbeskyttelse** (Motorer STA... / STP...)


AL41



1




2




leicht anziehen
tighten slightly
serrez sans forcer
Dra åt lätt
licht aandraaien
fissare leggemente
kiristä kevyesti
apretar suavemente
spændes let til

3



4



fest anziehen
tighten very much
serrez avec forcer
dra åt hårt
veel aandraaien
fissare molto
kiristä lujasti
apretar fuerte
spændes meget til

5

