

**de** Montageanleitung  
**en** Mounting instruction  
**fr** Instruction de montage  
**sv** Monteringsinstruktion  
**nl** Montage-aanwijzing  
**it** Istruzione di montaggio  
**fi** Asennus ohjeet  
**es** Instrucción de montaje  
**da** Monteringsvejledning

**Raumtemperaturfühler**  
**Room temperature sensor**  
**Sonde de température ambiante**  
**Rumtemperaturgivare**  
**Ruimtemperaturopnemer**  
**Sonda di temperatura ambiente**  
**Lämpötilan anturi huoneasennusta varten**  
**Sonda de temperatura de ambiente**  
**Rumtemperaturføleren**


## QAA100

## QAA160


## QAA170











QAA100



QAA160




QAA170



de Maßbilder  
en Dimensions  
fr Encombremnts

sv Måttuppgifter  
nl Maatschets  
it Ingombri

fi Mittapiirros  
es Dimensiones  
da Målskitse



Maße in mm  
Dimensions in mm  
Dimensions en mm  
Mått i mm  
Maten in mm  
Dimensioni in mm  
Mitat mm  
Dimensiones en mm  
Mål i mm