

- de** Montageanleitung
- en** Mounting instruction
- fr** Instruction de montage
- sv** Monteringsinstruktion
- nl** Montage-aanwijzing
- it** Istruzione di montaggio
- fi** Asennus ohjeet
- es** Instrucción de montaje
- da** Monteringsvejledning

- Tauchtemperaturfühler**
- Immersion temperature sensor**
- Sonde de température à plongeur**
- Dykgivare**
- Dompeltemperaturopnemer**
- Termosonda di mandata a immersione**
- Vesianturi**
- Sonda de temperatura de inmersión**
- Dykrørsføler**

QAE100B...


QAE160B...

QAE170B...



QAE1...-200




QAE100...




QAE170...



DN ≤ 80 mm



DN ≤ 80 mm




DN ≥ 80 mm

- de** Maßbilder
- en** Dimensions
- fr** Encombremets

- sv** Måttuppgifter
- nl** Maatschets
- it** Ingombri

- fi** Mittapiirros
- es** Dimensiones
- da** Målskitse


QAE1...-200:




Typ	A [mm]
QAE100B.1-200	100
QAE100B.2-200	160
QAE170B.1-200	100
QAE170B.2-200	160

Maße in mm
 Dimensions in mm
 Dimensions en mm
 Mått i mm
 Maten in mm
 Dimensioni in mm
 Mitat mm
 Dimensiones en mm
 Mål i mm


QAE1...-130, QAE1...-120





QAE100...




QAE160...




QAE170...



DN ≤ 80 mm



DN ≤ 80 mm




DN ≥ 80 mm

de Maßbilder
en Dimensions
fr Encombremets

sv Måttuppgifter
nl Maatschets
it Ingombri

fi Mittapiirros
es Dimensiones
da Målskitse

QAE1...-130, QAE1...-120:



Typ	A [mm]
QAE100B.1-130	100
QAE100B.2-130	160
QAE160B.1-120	100
QAE160B.2-120	160
QAE170B.1-120	100
QAE170B.2-120	160

Maße in mm
Dimensions in mm
Dimensions en mm
Mått i mm
Maten in mm
Dimensioni in mm
Mitat mm
Dimensiones en mm
Mål i mm