



- de** Montageanleitung
- en** Mounting instructions
- fr** Instructions de montage
- sv** Monteringsinstruktion
- nl** Montage-handleiding
- it** Istruzioni di montaggio
- fi** Asennusohje
- es** Instrucciones de montaje
- da** Monteringsvejledning
- pl** Instrukcja montażu
- cz** Montážní návod
- hu** Szerelési útmutató
- el** Οδηγίες εγκατάστασης
- ru** Инструкция по установке
- zh** 安裝指導

- Ventileinsatz**
- Valve insert**
- Garniture de vanne**
- Ventilinsats**
- Aspakkingset**
- Inserto per valvola**
- Venttiilin sisäkappale**
- Insertar en la válvula**
- Ventilindsats**
- Wkładka regulacyjna**
- Vložka**
- Szelepbetét**
- Μηχανισμός διακόπτη**
- Внутренние части клапана**
- 閥芯插件




ASR..N




MVS661.25..N	MVS661.25..EX	ASR..N
MVS661.25-016N	MVS661.25-016EX	→ ASR0.16N
MVS661.25-0.4N	MVS661.25-0.4EX	→ ASR0.4N
MVS661.25-1.0N	MVS661.25-1.0EX	→ ASR1.0N
MVS661.25-2.5N	MVS661.25-2.5EX	→ ASR2.5N
MVS661.25-6.3N	MVS661.25-6.3EX	→ ASR6.3N

MVS661..N / MVS661..EX


1




2




3




4



5



6



Issued by
Siemens Switzerland Ltd
Building Technologies Division
International Headquarters
Gubelstrasse 22
6301 Zug
Switzerland
Tel. +41 41-724 24 24

www.siemens.com/buildingtechnologies

© Siemens Switzerland Ltd, 2009

Technical specifications and availability subject to change without notice.