

Stückliste / Packing list

AGG3.111 / AGG3.110

AGG3.121 / AGG3.120

		DE

		EN
AGG3.111	AGG3.110	Anschlussbezeichnung ----- Terminal designation
		RAST5
1	50	X3-02
1	50	X3-03
1	50	X3-04
1	50	X3-05
1	50	X4-02
1	50	X5-01
1	50	X5-02
1	50	X5-03

		DE

		EN
AGG3.111	AGG3.110	Anschlussbezeichnung ----- Terminal designation
		RAST5
1	50	X6-03
1	50	X7-01
1	50	X8-02
1	50	X8-04
1	50	X9-04
1	50	X10-05
5	250	[/]

			DE	EN
AGG3.121	AGG3.120	Anschlussbezeichnung ----- Terminal designation	Beschreibung	Description
			RAST2,5	RAST2.5
1	50	X92	Modbus (COM)	Modbus (COM)
			RAST3,5	RAST3.5
1	50	X74	5-polig Stecker 1 x / Frequenzumrichter	5-pole connector 1 x / VSD
1	50	X64	5-polig Stecker 1 x / Reserve	5-pole connector 1 x / reserve
			RAST5	RAST5
1	50	X7-02	Brennstoffventil (V3)	Fuel valve (V3)
1	50	X75	Brennstoffmengenzähler	Fuel counter
1	50	X10-06	Flammenfühler QRA2... / QRA4.U	Flame detector QRA2... / QRA4.U