

Stückliste / Packing list

AGG3.111 / AGG3.110

AGG3.121 / AGG3.120

|          |          | <b>DE</b>   |
|----------|----------|---|
|          |          | -----   |
|          |          | <b>EN</b>   |
| AGG3.111 | AGG3.110 | Anschlussbezeichnung<br>-----<br>Terminal designation |
|          |          | <b>RAST5</b>  |
| 1        | 50       | X3-02   |
| 1        | 50       | X3-03   |
| 1        | 50       | X3-04   |
| 1        | 50       | X3-05   |
| 1        | 50       | X4-02   |
| 1        | 50       | X5-01   |
| 1        | 50       | X5-02   |
| 1        | 50       | X5-03   |

|          |          | <b>DE</b>   |
|----------|----------|---|
|          |          | -----   |
|          |          | <b>EN</b>   |
| AGG3.111 | AGG3.110 | Anschlussbezeichnung<br>-----<br>Terminal designation |
|          |          | <b>RAST5</b>  |
| 1        | 50       | X6-03   |
| 1        | 50       | X7-01   |
| 1        | 50       | X8-02   |
| 1        | 50       | X8-04   |
| 1        | 50       | X9-04   |
| 1        | 50       | X10-05  |
| 5        | 250      | [ / ]   |

|          |          |   | <b>DE</b>                               | <b>EN</b>                       |
|----------|----------|---|---|---------------------------------|
| AGG3.121 | AGG3.120 | Anschlussbezeichnung<br>-----<br>Terminal designation | Beschreibung                            | Description                     |
|          |          |   | <b>RAST2,5</b>                          | <b>RAST2.5</b>                  |
| 1        | 50       | X92   | Modbus (COM)                            | Modbus (COM)                    |
|          |          |   | <b>RAST3,5</b>                          | <b>RAST3.5</b>                  |
| 1        | 50       | X74   | 5-polig Stecker 1 x / Frequenzumrichter | 5-pole connector 1 x / VSD      |
| 1        | 50       | X64   | 5-polig Stecker 1 x / Reserve           | 5-pole connector 1 x / reserve  |
|          |          |   | <b>RAST5</b>                            | <b>RAST5</b>                    |
| 1        | 50       | X7-02   | Brennstoffventil (V3)                   | Fuel valve (V3)                 |
| 1        | 50       | X75   | Brennstoffmengenzähler                  | Fuel counter                    |
| 1        | 50       | X10-06  | Flammenfühler QRA2... / QRA4.U          | Flame detector QRA2... / QRA4.U |