


**de** Montageanleitung  
**en** Mounting instructions  
**fr** Instructions de montage  
**sv** Monteringsinstruktion  
**nl** Montage-handleiding  
**it** Istruzioni di montaggio  
**fi** Asennusohje  
**es** Instrucciones de montaje  
**da** Monteringsvejledning  
**pl** Instrukcja montażu  
**cz** Montážní návod  
**hu** Szerelési útmutató  
**ru** Инструкция по установке  
**el** Οδηγίες εγκατάστασης  
**zh** 安裝指導




**Stellantriebe für Hähne**  
**Actuators for slipper valves**  
**Servomoteurs vanne à secteur**  
**Ställdon för vridslidventiler**  
**Servomotoren voor kranen**  
**Servomandi per valvola a settore**  
**Venttiilin toimimoottorit**  
**Forstillingsorganer sleidehaner**  
**Motorer for haner**  
**Siłowniki do zaworów obrotowych**  
**Pohony pro kohouty**  
**Állítómotorok csapokhoz**  
**Приводы для поворотных клапанов**  
**Κινητήρες για περιστροφικές βάνες**  
**滑阀执行器**









**SQK349.00/209**  
(+ ESBE)



<b>1</b>					
	SQK349..	+ VRG131 VRG132 VRG133	VRG141 VRG142 VRG143	+ 	





1	♀	♂			♂					
		DN15..25	DN20..50		DN15..25	DN20..50				
SQK349..	+	3MG15 3MG25 3MG28 3MG20 3MG22	G119 G125 G132 G138 G151	4 173 5501 0  16 4512Z12		4MG15 4MG20 4MG25	G419 G425 G432 G438 G451	TM22 T20 T25 T32	4 173 5501 0  16 4512Z12	
			F120 F125 F132 F140 F150	4 173 5502 0  8 00116			BIV25 BIV20 BIV50	FRONT	4 173 5502 0  8 00116	

