


de  
en  
fr  
sv  
nl  
it  
fi  
es  
da  
pl  
cz  
hu  
el  
ru  
zh

Montageanleitung  
Mounting instructions  
Instructions de montage  
Monteringsinstruktion  
Montage-aanwijzing  
Istruzioni di montaggio  
Asennusohje  
Instrucciones de montaje  
MonteringsvejleDN ing  
Instrukcja montażu  
Montážní návod  
Szerelési útmutató  
Οδηγίες εγκατάστασης  
Инструкция по установке  
安裝指導


Adapter  
Adapter  
Adaptateur  
Adapter  
Adapter  
Adattatore  
Sovitesarja  
Adaptador  
Adapter  
Łącznik  
Adaptér  
Adapter  
Προσαρμογέας  
Переходной фитинг  
配套连接件



**ALF41B..**



74 319 0749 0  
M4030

DN	VXF41..		ALF41B..	#	
15	VXF41..	▶ VXF53.. +	<b>ALF41B15</b>	S55845-Z110	4x M12x90 mm
25	VXF41..4		<b>ALF41B25</b>	S55845-Z111	4x M12x90 mm
40	VXF41..5		<b>ALF41B40</b>	S55845-Z112	4x M16x90 mm
50			<b>ALF41B50</b>	S55845-Z113	4x M16x90 mm
65	VXF41..	▶ VXF43.. +	<b>ALF41B65</b>	S55845-Z114	4x M16x90 mm
80	VXF41..4		<b>ALF41B80</b>	S55845-Z115	8x M16x110 mm
100	VXF41..5		<b>ALF41B100</b>	S55845-Z116	8x M16x110 mm
125			<b>ALF41B125</b>	S55845-Z117	8x M16x110 mm
150			<b>ALF41B150</b>	S55845-Z118	8x M20x110 mm

