



- de** Montageanleitung
- en** Mounting instructions
- fr** Instructions de montage
- sv** Monteringsinstruktion
- nl** Montage-aanwijzing
- it** Istruzioni di montaggio
- fi** Asennusohje
- es** Instrucciones de montaje
- da** Monteringsvejledning

- Raumtemperaturfühler
- Room temperature sensor
- Sonde de température ambiante
- Rumstemperaturgivare
- Ruimtemperatuuropnemer
- Sonda di temperatura ambiente
- Lämpötilan anturi huoneasennusta varten
- Sonda de temperatura de ambiente
- Rumtemperaturføleren


AQR2531...



	min. 1 x	max. 1 x
	0.25 mm ²	2.5 mm ²
	0.25 mm ²	1.5 mm ²
	0.25 mm ²	1.5 mm ²

1408T01

A



B

