



de Montageanleitung
en Mounting instructions
fr Instructions de montage
sv Monteringsinstruktion
nl Montage-aanwijzing
it Istruzioni di montaggio
fi Asennusohje
es Instrucciones de montaje
da Monteringsvejledning

Differenzdruckfühler
Differential Pressure Sensors
Sonde de pression différentielle
Differenstryckgivare
Drukverschilopnemer
Sonda di pressione differenziale
Paine-eroanturit
Sondas de diferencia de presión
Trykdifferensføler


QBM4000-..
QBM4100-..




QBM4000-..
Output 0...10 V





Pin	
3	(GL)
1	(U1)
2	(M)



QBM4100-..
Output 4...20 mA



Pin	
3	(G)
1	(I)
2	(-)



For additional information please refer to the [Sensor Installation Handbook](#)

and <http://siemens.com/bt/download>



→ search for "QBM4000" or "QBM4100"