


RWB27 Timeswitch



Daily Programming

RWB27 Controls



Introduction

This booklet gives you easy to follow instructions allowing you to set your RWB27 Timeswitch to the Daily, (same ON/OFF times each day) program.

Contents

- ① How do I change/set the ON/OFF times?
- ② How do I review the current ON/OFF times?
- ③ What do the switching options mean?
- ④ How do I select my Switching Options?
- ⑤ How do I set my holiday program?
- ⑥ How do I activate my holiday program?
- ⑦ What do the buttons do?
- ⑧ Notes on RWB27 settings.

To make it easier to follow, the buttons you should be using are coloured grey.

RWB27 Daily





At first installation display will show as above unless reset is activated.



At first installation display will show as above when reset is activated.


How do I change/set the ON/OFF times?

- Press left hand button MENU
- Press top middle button  until SET PROGRAM is shown
- Press left hand button SELECT display will show





(continued on next page)


To change 1st ON time press
SELECT, time will flash, change
times by using \triangle +/ ∇ , when
desired time is in the display press
ENTER display will show




- Repeat as above until last OFF time is entered
display will show
press EXIT to return to MENU




How do I review the current ON/OFF times?

- Press left hand button MENU
- Press top middle button  until REVIEW PROG is shown
- Press left hand button SELECT
- 1st ON time will be shown




(continued on next page)

- Press top middle button 
1st OFF will be shown



- Continue above two actions until
last OFF is shown



- Press right hand button BACK
then press again EXIT
(this will return you to MENU)



What do the switching options mean?

AUTO

This means that the RWB27 will switch ON and OFF according to the programmed times

MANUAL OFF

This means that the RWB27 will be permanently OFF

MANUAL ON




This means that the RWB27 will be permanently ON

ONCE

This means that the RWB27 will switch ON at the first ON time and switch OFF at the last OFF time you have programmed ignoring any ON/OFF times in between. This is also referred to as All Day.



How do I select my four switching options?

- Press left hand button MENU
Display shows _____
- Press left hand button SELECT
twice, Display shows _____
- Press top middle button ▲ until
your switching option is displayed
AUTO*
MANUAL OFF*
MANUAL ON*
ONCE*
*see previous page for details
- Choose desired option by pressing
ENTER





(continued on next page)

- Press right hand button BACK
- Press right hand button EXIT
Display shows







How do I set my holiday program?

- Press left hand button MENU
- Press top middle button \triangle until SET HOLIDAY is shown
- Press left hand button SELECT display shows _____ number of holiday days will flash, change amount of days (1-99) by using \triangle +/- ∇ , when desired amount of days is in the display press left hand button ENTER, then right hand button EXIT to return to MENU



How do I activate my holiday program?

- Press left hand button MENU
SET STATUS is shown,
press SELECT
- Press top middle button 
until HOLIDAY is shown
- Press left hand button SELECT
display will flash as shown
your system is now in HOLIDAY
mode (OFF) and will countdown
the amount of days you have set
it for, at the end of which it will
automatically go back to your
normal set program.
You can also press CANCEL to
return to normal program mode.



What do the buttons do?

ADV (ADVANCE)

This brings forward the next switching time, for example:-

- (a) if your times were ON 7am and OFF 9am - ON 5pm and OFF 10pm and you pressed the ADV at 4pm your heating would come ON straight away and go OFF at 10pm.
- (b) if your times were ON 7am and OFF 9am - ON 5pm and OFF 10pm and you pressed the ADV at 9pm your heating would go OFF straight away and come ON at 7am the next morning.

+ HRS

This allows you to either increase your heating time in multiples of one hour (up to a maximum of 3 hours) during a timed ON period or to bring on the heating in multiples of one hour (up to a maximum of 3 hours) during an OFF period.

Notes on RWB27 settings.


Your RWB27 comes with the correct day of the week, date and time preset, it will also automatically switch to and from daylight saving hours.

Should you at anytime or for any reason need to manually adjust the clock settings, please refer to the following pages.



To manually adjust the clock?

- Display shows _____
Press MENU



- Press bottom middle button 
until display shows _____
Press SELECT



- Alter time using +/-
buttons to scroll, when correct time
is shown press left hand button
ENTER display shows _____



(continued on next page)

- Alter year using \triangle +/ ∇ buttons, when correct year is shown press left hand button ENTER, display shows _____



- Alter month using \triangle +/ ∇ buttons to scroll, when correct month is shown press left hand button ENTER display shows _____



- Alter day of the month using \triangle +/ ∇ buttons, when correct day of the month is shown press ENTER then press right hand button EXIT display shows _____



What is a programmer?

... an explanation for householders

Programmers allow you to set 'On' and 'Off' time periods. Some models switch the central heating and domestic hot water on and off at the same time, while others allow the domestic hot water and heating to come on and go off at different times.

Set the 'On' and 'Off' time periods to suit your own lifestyle. On some programmers you must also set whether you want the heating and hot water to run continuously, run under the chosen 'On' and 'Off' heating periods, or be permanently off.

The time on the programmer must be correct. Some types have to be adjusted in spring and autumn at the changes between Greenwich Mean Time and British Summer Time.

You may be able to temporarily adjust the heating programme, for example, 'Override', 'Advance' or 'Boost'. These are explained in the manufacturer's instructions.

The heating will not work if the room thermostat has switched the heating off. And, if you have a hot-water cylinder, the water heating will not work if the cylinder thermostat detects that the hot water has reached the correct temperature.

NOTES

NOTES

NOTES

NOTES