



5SY4, 5SY5 supplementary protectors




5ST3 auxiliary switch 5ST3 fault signal contact

can be used with 5SY4, 5SY5, 5SP4



5SP4 supplementary protectors



5ST3 shunt trip 5ST3 undervoltage release

can be used with
5SY4, 5SY5, 5SP4

