

# Pushbutton Units and Indicator Lights

## Class 50 Standard Duty Pushbutton Stations

Heavy Duty - 10A 600V AC NEMA B600

### Selection and ordering data

Actuator identification	Degree of protection	Contacts / voltage	Number of command points	Order No.	Weight approx.	
					lbs.	Unit
A = Momentary pushbutton, surface, label "START"	NEMA 4	1NO - 1NC	1	50HA1E1		1
A = Momentary pushbutton, surface, label "STOP"	NEMA 4	1NO - 1NC	1	50HA1E2		1
A = Momentary pushbutton, surface, label "RESET"	NEMA 4	1NO - 1NC	1	50HA1E4		1
A = Momentary pushbutton, surface, label "JOG"	NEMA 4	1NO - 1NC	1	50HA1E5		1
A = Maintained selector switch, surface, label "SAFE-RUN"	NEMA 4	1NO - 1NC	1	50HA1E6		1
A = Maintained selector switch, surface, label "OFF-ON"	NEMA 4	1NO - 1NC	1	50HA1E7		1
A = Maintained selector switch, surface, label "JOG-RUN"	NEMA 4	1NO - 1NC	1	50HA1E8		1
A = Maintained selector switch, surface, label "HAND-OFF-AUTO"	NEMA 4	1NO - 1NC	1	50HA1E9		1
B = Momentary pushbutton green, surface, label "START"	NEMA 4	1NO - 1NC	2	50HA2E1		1
A = Momentary pushbutton red, surface, label "STOP"						
B = Momentary pushbutton, surface, label "FORWARD"	NEMA 4	1NO - 1NC	2	50HA2E2		1
A = Momentary pushbutton, surface, label "REVERSE"						
B = Momentary pushbutton, surface, label "UP"	NEMA 4	1NO - 1NC	2	50HA2E3		1
A = Momentary pushbutton, surface, label "DOWN"						
B = Momentary pushbutton, surface, label "OPEN"	NEMA 4	1NO - 1NC	2	50HA2E4		1
A = Momentary pushbutton, surface, label "CLOSE"						
B = Momentary pushbutton, surface, label "FAST"	NEMA 4	1NO - 1NC	2	50HA2E5		1
A = Momentary pushbutton, surface, label "SLOW"						
C = Momentary pushbutton, surface, label "FORWARD"	NEMA 4	1NO - 1NC	3	50HA3E1		1
B = Momentary pushbutton, surface, label "REVERSE"						
A = Momentary pushbutton, surface, label "STOP"						
C = Momentary pushbutton, surface, label "UP"	NEMA 4	1NO - 1NC	3	50HA3E2		1
B = Momentary pushbutton, surface, label "DOWN"						
A = Momentary pushbutton, surface, label "STOP"						
C = Momentary pushbutton, surface, label "OPEN"	NEMA 4	1NO - 1NC	3	50HA3E3		1
B = Momentary pushbutton, surface, label "CLOSE"						
A = Momentary pushbutton, surface, label "STOP"						
C = Momentary pushbutton, surface, label "START"	NEMA 4	1NO - 1NC	3	50HA3E9		1
B = Momentary pushbutton, surface, label "JOG"						
A = Momentary pushbutton, surface, label "STOP"						
C = Momentary pushbutton, surface, label "FAST"	NEMA 4	1NO - 1NC	3	50HA3E4		1
B = Momentary pushbutton, surface, label "SLOW"						
A = Momentary pushbutton, surface, label "STOP"						

