

<b>de</b>	Montageanleitung
<b>en</b>	Mounting instructions
<b>fr</b>	Instructions de montage
<b>sv</b>	Monteringsinstruktion
<b>nl</b>	Montage-aanwijzing
<b>it</b>	Istruzioni di montaggio
<b>fi</b>	Asennusohje
<b>es</b>	Instrucciones de montaje
<b>da</b>	Monteringsvejledning


**Dreh-/Hubaufbausatz für Bodenmontage**  
**Rotary/linear set for duct mounting**  
**Kit de conv. rot./lin. pour montage sur gaine**  
**Slagomvandlare med konsol**  
**Roterende lineairset voor kanaalmontage**  
**Set conversione rotativo/lineare per montaggio a canale**  
**Kääntö/työntöliikesarja kanava-asennusta varten**  
**Equipo para transmisión rotativa/lineal, montaje en conducto**  
**Konsol for bundmontering**

**ASK71.1****A**

**Lieferumfang**  
**Supply**  
**Contenu**

**Leverans**  
**Leveringsomvang**  
**Contenuto**


**Toimituslaajuus**  
**Contenido**  
**Leverancens omfang**


**B**

**Montage**  
**Mounting**  
**Montage**

**Montering**  
**Montage**  
**Montaggio**

**Asennus**  
**Montaje**  
**Montering**





**Anwendung**  
Application  
Indications

**Hänvisningar**  
Aanwijzingen  
Messa in servizio

**Huomautuksia**  
Indicaciones  
Bemærkninger

