


Installation Instructions



⚠ DANGER

Hazardous Voltage.
Will cause death, serious injury or substantial property damage.

Turn off power supplying this equipment before working inside.


Note: This instruction outlines the recommended general installation procedure. For installation by a qualified person, as defined by all local electrical codes and/or the National Electrical Code®.

Step 1. Turn off and lock off the power supplying the device before working inside.

Step 2. Remove 1/2" Keps Nuts and Washers from studs on each terminal bus and bus extension, as shown in Figure 1.

Step 3. Install Bus Extension on center studs of each terminal bus as shown in Figure 2. Secure Bus Extension with 1/2" Keps Nuts and Washers, torque 450-500 lb.-in.

Step 4. Install Lugs on each terminal bus and Bus Extension as shown in Figure 3. Secure Lugs with 1/2" Keps Nuts and Washers, torque 450-500 lb.-in.



Lug Kit No.	Wire Range	Lug Qty	Bus Extension Qty
LK18500N2CD	1/0-500 kcmil CU	12	3
LK38500N2CD	1/0-500 kcmil CU	16	4
LK18750N2AD	1/0-750 kcmil AL	12	3
LK38750N2AD	1/0-750 kcmil AL	16	4

