



Instructions

⚠ DANGER

Hazardous Voltage.
Will cause death, serious injury or substantial property damage.

Turn off power supplying this equipment before working inside.

This instruction outlines the recommended general installation procedure. For installation by a qualified person, as defined by all local electrical codes and/or the National Electrical Code®.

⚠ SAFETY INSTRUCTIONS

Turn off and lock off the power supplying the device before working inside.

Kit Contents:

- (1) 750 kcmil Lug Assembly (Lug Set Screw Torque 500 lb.-in.)
- (2) 1/4-20 x 1/2 Screws
- (2) Washers

1. Remove insulating barrier and retain for use later.
2. Remove (2) 1/4-20 Nut/Washer Assemblies as shown in Figure 1 and retain for use later. Remove Bus/Connector Assembly.
3. Remove (2) 1/4-20 Screws and Washers from back of Bus/Connector Assembly. Discard Screws, Washers, and Lug Assembly.
4. Secure new Lug Assembly (provided with kit) to Connector as shown in Detail A with the (2) 1/4-20 Screws and Washers provided with kit. Torque screws to 45-60 lb.-in.
5. Re-Install Bus/Connector Assembly to bus using Nut/Washer Assemblies from Step 2. Torque to 60-65 lb.-in.
6. Reinstall insulating barrier.

Figure 1

Figure may vary depending upon module used. Some modules may have multiple lugs per phase.

