


IF IN DOUBT ASK  
DO NOT SCALE



NOTE.  
REMOVE SIDEPLATE TO GAIN ACCESS TO ON-SITE PILOT WIRE CONNECTIONS. PILOT WIRES TO BE INSERTED THROUGH GROMMET BEFORE TERMINATING. ENSURE THAT THE BUSH SECURING THE MODEM CABLE IS CORRECTLY POSITIONED BEFORE REFITTING SIDEPLATE.

**NOT SUBJECT TO UPDATE  
ONCE COPIED / PRINTED  
OR DOWNLOADED**

**MATERIAL:**

Dimensions in millimetres : Surface texture in micrometres.  
Machine where marked ✓  
For explanation of dimensions, tolerances, notes etc. see B.S.308.  
Limits on untoleranced unmachined dimensions to  $\pm$  \_\_\_\_\_  
Limits on untoleranced machined dimensions to B.S.4500:  
i.e. up to  $6\pm 0.1$ ; over 30 to  $120\pm 0.3$ ; over  $315\pm 0.8$ ;  
over 6 to  $30\pm 0.2$ ; over 120 to  $315\pm 0.5$ ;  
General unmachined angular tolerance  $\pm$  \_\_\_\_\_

Copyright © 2013

Reyrolle Ltd.

3 ROW	21/05/13	MAN3633/693	ID
2 ROW	15/9/06	MN693/2833	
1	17/09/04	CHANGE	
ISSUE	DATE	NOTED	

Finish:

Title: OUTLINE, PANEL DRILLING & ON-SITE PILOT WIRE CONNECTIONS FOR SOLKOR-N RS232 PILOT WIRE MODEM

First used on:

Treatment:

Similar Articles:

Supersedes:

Reyrolle Protection

Original Scale: 1:2

Drq.No. 2693X10003

DRAWN: MMather	CHECKED: RD.WATSON	APPROVED: RD.WATSON	DATE: 20/09/04	I.E.	OPS.	PCP.	Purch. Spec.	TQ.	EAC	CE.	STD.	A4h
----------------	--------------------	---------------------	----------------	------	------	------	--------------	-----	-----	-----	------	-----